

## Knob-operated 3-position selector switch actuator P3



### Ordering code

SP22-  .

	Colour
CZ	● black
C	● red
G	● yellow
Z	● green
N	● blue
B	○ white



### Pushbutton type

<b>P3</b>	maintained
<b>P3C</b>	self-return from right
<b>P3CC</b>	self-return from right and left

**P31** - double pusher, divided:  
in pos. "I" makes 2, 3 or 4 circuits  
in pos. "II" makes 1 or 2 circuits

**P32** - double pusher, divided:  
in pos. "I" makes 1 or 2 circuits  
in pos. "II" makes 2, 3 or 4 circuits

### Diagrams



### Technical data

Actuator weight 12,5 g

### Dimensions

