Shaft clamps for RSI, PRZK RSI160-6621\P01



Ordering code

RSI160-6621\P01

Product description

Mounting a shaft clamp in the place of the RSI, PRZK disconnector knob allows for conversion of W02, W03 assembly (with a knob on the disconnector) to W01 assembly (for external knob)

Dimensions



